

# KIT MASTERS

## 8009X / 8010X / 8011X Kit Assembly Instructions

1. Remove old fan clutch
2. a. For 8009X or 8011X - Spacer must be installed between pulley and fan clutch (see image below)  
b. For 8010X - Add hex head spacer between pulley and fan clutch (see image below)
3. Bolt new fan clutch to pulley

**This fan clutch requires air to disengage, so reversing the solenoid is required.  
If solenoid is not reversible, you must purchase Part #3282.**

